

---

Subject: Re: Kustom III PA

Posted by [steven](#) on Mon, 15 Jun 2015 10:26:26 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

rig up a way to pump signal into pins 2 and 3 of the input connector on you 5065 or whatever driver board to confirm that at least that end of the amp is working.

Do not pull that connector as the amp needs the ground, so just tack solder to the board .

The turn on thump is a good sign that the output stage is working!

---