
Subject: Re: '69-'70 Kustom 100 2 power cord upgrade
Posted by [chicagobill](#) on Tue, 05 Dec 2023 18:11:50 GMT
[View Forum Message](#) <> [Reply to Message](#)

The tank you have is a C tank. So all you have to do is to add a jumper on the input jack shell connection to ground, just like the one that is on the output jack.

Once both jacks are grounded you should have working reverb.
