Subject: k100-2

Posted by stevebass on Fri, 22 Apr 2011 04:11:46 GMT

View Forum Message <> Reply to Message

Hi, I have a June 1968 Blue tuck n roll k100-2 head. It has the 2 prong power cord attached to it. I would like to modify this to have a grounded 3 prong cord. Should I do this, or leave it original? If I shouldn't, then why? has anyone done this or knows how much this would cost? Is there a way to ground it without modifying the originality? I know I would play it alot more if it was grounded, I get shocked too much the way it is right now.

Any advice would help, thanks.

Subject: Re: k100-2

Posted by sunnhead on Fri, 22 Apr 2011 05:38:56 GMT

View Forum Message <> Reply to Message

its easy to do and don't cost much, It wont affect the value of the amp, are you handy with a soldering gun?

-Steve

Subject: Re: k100-2

Posted by stevebass on Fri, 22 Apr 2011 05:49:40 GMT

View Forum Message <> Reply to Message

I have used one before to rewire guitars and pedals, so i'm decent with it. How would you do it?

Subject: Re: k100-2

Posted by sunnhead on Fri, 22 Apr 2011 05:58:14 GMT

View Forum Message <> Reply to Message

well you need to get a new cord, there is a Green Black and white. The green is the ground, use a screw on the chassis to ground that one out. The black is hot and the white is ground also on the chassis. If you want my help I can make a video for you, or if you ever wanna travel down to mankato I can do it for you.

-Steve

Subject: Re: k100-2

Posted by chicagobill on Fri, 22 Apr 2011 15:21:42 GMT

View Forum Message <> Reply to Message

Be careful there! The white wire is the neutral line, it is not really ground, and should not be connected to the chassis.

We have discussed the replacement of the power cord for many years now. Replacing them does not really affect the value of the amp and it will make the amp safer to use if it is done correctly.

Here on the board, Conrad likes to use Hoover floor machine power cords that are as long as the originals and also have the plug clip to hold the wire neatly on the back of the amp when stored away. If you search the board you will probably find one of his posts that detail the procedure.

Subject: Re: k100-2

Posted by sunnhead on Fri, 22 Apr 2011 15:50:37 GMT

View Forum Message <> Reply to Message

yeah my bad I ment to attach the white one with the white neutral on the amp, boy that made me sound like a novice live replaced many a power cords...

-Steve