

---

Subject: Re: Kustom 100 blowing fuse

Posted by [JDinPA17603](#) on Tue, 23 Apr 2019 16:12:14 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

time traveler

If one of the two resistor R23/R25 you changed out was a 200 ohm resistor then you need to use the schematic labeled 5033(8/70) from the PC boards by number list. On that schematic R22 and R24 are 200 ohm 1/2 watt 1% resistors. R20 and R25 are 510 ohm 1/2 watt 5% and R21 and R23 are 0.51 ohm 5 watt ceramics.

If the good one you replaced (R23 or R25) with a 150 was already a 150 then R24 and R22 are 0.5 ohm 5 watt ceramic resistors, and R21 and R26 are 510 ohm 1/2 watt 5% resistors.

John

---