
Subject: K200b-2

Posted by [Iowa Boy](#) on Fri, 25 Sep 2015 03:58:21 GMT

[View Forum Message](#) <> [Reply to Message](#)

Okay guys starting to repair all these amps and getting them up to par. This K200, the reverb and tremolo neither worked. Broken wires inside pan was the reverb issue. Fixed, however when I plug in my generic double footswitch if I just push the plug so the tab connects to the jack, switch works just like it is suppose to...even lights up. However when the plug is pushed all the way into the jack, footswitch now doesn't work at all and no light. Stereo jack so I understand that the tip controls one circuit and the other part of the shaft separated by the insulator is the other and then remainder after the second insulator is the ground.

Tremolo.....nothing.

Where do we start?
