

---

Subject: Re: K150-6 pumps out DC voltage when powered on.

Posted by [corybrown](#) on Sun, 15 Mar 2020 23:05:20 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I am so sorry. I misread your post before and I thought you meant Q7. I just now removed C7 and we are back at 0V on the output.

It's not a stable 0V it keeps bouncing between 0V and -.25V. Not sure if that's a problem.

Thanks

---