Subject: loud pop early K200A-1 Posted by kustomhead on Sun, 15 Dec 2013 05:00:49 GMT View Forum Message <> Reply to Message

When plugging a guitar cord into the both hi and low inputs on the left channel there's a loud distorted pop/noise as it first makes contact with the jack. Also when I click on my boost pedal it makes a loud pop. The right channel works fine. Could it have to do with the 200U Memcor or GE .0047 50 volt cap that bridges the hi and low inputs? Anybody have this phenom? It's a very early A model 4-150-1 with serial# 18383.