Subject: K-200B-2 normal channel

Posted by slk854 on Thu, 28 Jul 2016 19:57:42 GMT

View Forum Message <> Reply to Message

I just got a 200B-2 and the bright channel seams to working ok. When I connect to the normal channel I have nothing, but when I turn the volume knob back and forth on that channel I have some sound. It is just what is input sound. It is just more like a scratchy volume sound but it will not pick up anything that is plugged into it. Any suggestions are greatly appreciated

Steve