Subject: K200B-2 Hissing

Posted by slk854 on Sun, 23 Oct 2016 15:32:11 GMT

View Forum Message <> Reply to Message

I have one of my 200's that has a hiss when you power up the amp. All knobs can be turned down to nothing but still the hiss. When you start playing the sound does drown out the hiss, but it is still there. I can flip the power switch left or right and no difference. It is not unbearable but it is annoying to hear. Any suggestions to try???

Steve