
Subject: kasino club

Posted by [ktaylor](#) on Sat, 21 Sep 2002 19:18:19 GMT

[View Forum Message](#) <> [Reply to Message](#)

My kasino club has very low volume unless you turn up tone controls mainly the bass tone. You get volume then, but there is a loud hissing or whoosing noise. Very noticeable. Any ideas on what might be causing this. I don't have any schematics. Sure would appreciate any help. Thank`s,

Ken Taylor

Subject: Re: kasino club

Posted by [ktaylor](#) on Sat, 28 Sep 2002 18:57:56 GMT

[View Forum Message](#) <> [Reply to Message](#)

Can someone please help me out here. I don't have a clue where to start.

Ken

Subject: Re: kasino club

Posted by [Komboking](#) on Tue, 01 Oct 2002 01:36:54 GMT

[View Forum Message](#) <> [Reply to Message](#)

First place I'd look is loose grounds and cold solder joints.....
